


Haven Select Pivoting Deflector H#SPM



Handling

Be aware toughened glass can shatter if not handled correctly. It should not be subjected to any sharp impact and it is essential to protect the glass by resting it on a soft protective surface during installation such as cardboard or carpeting. It is recommended to wear PPE at all times during installation.



Pre-Installation Checks

1. Please take time to read these instructions prior to installing your product, including the Tray Sizes section below.
2. Check you have the correct product, by looking at the labels on the side of the product packaging.
3. Check all the product components and fixing kits are in the box - [these are listed on the next page](#).
4. Please check the product for defects or damage, once the installation has commenced we cannot accept responsibility for any defects or damage.
5. Before you commence any drilling check there are no hidden electrical cables and/or water pipes.
6. No attempt should be made to re-work the toughened safety glass.
7. The installation of the product should be performed by two persons.
8. It is strongly recommended the product is fitted on a tiled surface or similar waterproof surface - which are tiled and grouted before product is installed.
9. It is strongly recommended that the walls the product is going to be installed on are vertical, and the floor/tray is level.
10. Please note that some natural misting may occur when you remove this product from its packaging, due to the addition of the glass protection pre-coating. If this does occur this can easily be removed with a soft, dry cloth.

Tray Sizes



Important: You **MUST** measure your tray before you proceed with installation. Haven Select Products have been designed to fit on standard Roman trays. Refer to Step 1 for a guide on how to measure your tray accurately before proceeding any further - [Roman](#) will not be liable if you begin installation without correctly measuring your tray, to the realisation it doesn't fit.

Consumer Guarantee

Please make sure the purchaser/end user completes and returns the guarantee card which is enclosed with this product. Failure to validate the Guarantee will mean only the 1 Year Statutory Guarantee will apply.




Equipment Checklist: Not Supplied



No.	Description	Qty.			
1	Glass Panel	1			
2	Brush Seal	1			
3	LH Panel Moulding	1			
4	RH Panel Moulding	1			
5	Pivot Channel	1			
6	Bottom Seal	1			




Step 1 - Pre-Installation Checks





1. Make sure the tray is installed as per the manufacturer's instructions.
2. Check your Tray and Walls are level on all sides (the bubble on the spirit level must be in the centre of the 2 lines).
3. Check the Wetroom Panel has been fitted Level.
4. Stand in the tray and check that there is no adverse movement (correct if necessary).
5. The walls should be tiled and grouted up to the tray.
6. The tiles and the tray should be sealed using a good quality bathroom sealant:
 - Spray the seal and joints with the shower head and check for leaks when the silicon has cured.
 - Check the plumbing for leaks.
 - DO NOT plasterboard over the tray.
 - DO NOT grout the tiles when the enclosure has been fitted, the grout may discolour the aluminium profiles.

Step 2 - Fitting the Panel

IMPORTANT: Please ensure the Pivoting Panel is fitted the correct way round, see stage 4 below.



1. Run a bead of silicone down the full length of the aluminium on the inside face in the sealing groove.
2. Lift the aluminium onto the tray and then push sealing groove onto the panel. Use tape to secure the aluminium into place and leave the tape in position for 24 hours.
3. Once the silicone has had 24 hours to cure remove the tape and unscrew the top panel moulding from the aluminium.
4. Ensure that the Pivoting Panel is the correct way before fitting, the "P" shaped extrusion should be positioned so that the Flat Face is to the inside of the showering area and the Round Face to the outside.
5. Offer the glass panel onto the bottom panel moulding then reattached the top moulding so the panel is then secured into position.
 - **IMPORTANT:** If you are fitting a product with a print, please ensure you fit the print on the outside.
6. Fit the bottom seal to the moving panel ensuring the deflector faces inward (trim to length as required).



Trouble Shooting Guide

Should you experience any problems during installation please refer to the Trouble Shooting Guide or contact Customer Relations on:
+44 (0) 1325 328033

To enable customer relations to provide you with an excellent level of service it is important that you quote your product Code and Reference Number - these can be found on the Guarantee card.

Problem	Solution
Leaking	<ol style="list-style-type: none">1. Ensure your Product is installed in accordance with Step 1 of the H#SP Manual. The Deflector's Pivoting Channel must finish in line with the Inside edge of the Tray. <p><u>Important: This enclosure should be water tested conforming to BS EN 14428</u></p>

Important Information to help you maintain your Product:

The following information is all you need to keep your product looking new.

Our products are generally maintenance free, however it may be necessary to lubricate wheel assemblies and other moving parts such as hinges from time to time.

Clean your product using a mild detergent diluted in water and then polished off using a soft cloth.

If you live in a hard water area, periodically clean your product using a 50/50 solution of white vinegar and water. The solution should be left on the enclosure for approximately 5 minutes then rinsed off using warm water. This method of cleaning should remove lime scale residue.

It is strongly recommended that a quality silicone spray is used.

A list of Donts

1. Don't use acidic based products which are unsuitable for cleaning enamel surfaces.
2. Don't use abrasive cleaners or cleaners using bleach or solvents, these products will adversely affect the finish of the aluminium profiles.
3. Don't use scouring pads, powder or any sharp instruments when cleaning the enclosure.